

11.4.1 READING KEY FOR DETAILED DRAWING OF TNS 21.0011

<i>Ref.</i>	<i>Code</i>	<i>Description</i>	<i>Q.ty</i>
1	210128	HOLDER FOR TNS SHAFT FOR TP6	1
2	740151	SELF LUBRICATING BUSHING M5 M8X1X7	1
3	850408	LOCKING HANDLE MR40P M5X10	1
4	210136	SCREW TCEI M4X25	2
5	210129	TNS HOLDING SHAFT FOR TP6	1
6	210402	LEFT SIDE HOLDING LEVER	1
7	210410	RIGHT SIDE HOLDING LEVER	1
8	210401	FIXING RING FOR SIDE LEVER	2
9	930075	SCREW TCEI M4X20	4
10	210102	BUSHING F08/12/08	2
11	400211	ENSAT BUSHING M5/M8X10	2
12	210407	RIGHT ECCENTRIC	1
13	210408	LEFT ECCENTRIC	1
14	210409	GLYCODUR BUSHING Ø8 Ø10 h12	2
15	400210	KNOB M5X16	2
16	210403	LOWER DRIVING SHAFT	1
16a	210406	LOWER ROLLER	1
17	500010	COMPLETE PULLEY Z11	1
18	500018	SCREW PP M4X4 UNBRAKO	1
19	210404	UPPER SHAFT	1
19a	210405	UPPER ROLLER	1
20	500016	CLIP Ø8	2
21	510002	TOOTHED WHEEL FOR FEEDERS AND TNS	1
21a	510056	TOOTHED PULLEY Z33XL037	1
21b	400512UK	TCEI SCREW M3X12 UNBRAKO	3
21c	510057	GEAR Z50 M1 FOR CS10-CS30-TNS	1
21d	210119	SCREW PP M6X12	2
22	550007	TOOTHED BELT 140 XL	1
23	210127	COMPLETE COVER FOR TNS FOR TP6	1
23a	210135	SCREW TBEI M5X40	1