


## - 11 - SPARE PARTS

### 11.1 WARNING FOR THE CUSTOMER

Before ordering any particular spare part, it is always necessary to specify the serial number of the machine to which the part shall fit.

### 11.2 DETAILED DRAWING OF MACHINE CODE 104.0001 SEP2M-600 MOTOR P.C.B. SEPARATOR 1 LINEAR BLADE 600mm AND 1 CIRCULAR BLADE 110V



**DETAILED DRAWING UPPER PART**

