

- 11 - SPARE PARTS

11.1 WARNING FOR THE CUSTOMER

Before ordering any particular spare part, it is always necessary to specify the serial number of the machine to which the part shall fit.

11.2 DETAILED DRAWING OF MACHINE CODE 104.0000 SEP2-600 MANUAL PC BOARD SEPARATOR 1 LINEAR BLADE 600mm AND 1 CIRCULAR BLADE



