

caricatori per
componenti
assiali sfusi

CS10-CS20 CS30-CS40

feeders for
loose axial
components




CARICATORE CS10 per :TP6, TP6/PR-B, TP6/S
CS10 FEEDER for: TP6, TP6/PR-B, TP6/S
(Cod. 51.0100)



CARICATORE CS20 per TP6/V-PR
CS20 FEEDER for TP6/V-PR
(Cod.51.0200)



CARICATORE CS30 per TP6/V
CS30 FEEDER for TP6/V
(Cod.51.0300)



CARICATORE CS40 per TP6/PR-F
CS40 FEEDER for TP6/PR-F
(Cod. 51.0400)

LARGH. = 22 cm
PROFONDITA' = 24 cm
ALT. = 10 cm
IMBALLO = 29x24x24 cm
VOLUME = 0,020 m³
PESO CARICATORE = 2 kg
PESO LORDO = 3 kg

WIDTH = 22 cm
DEPTH = 24 cm
HEIGHT = 10 cm
PACKING = 29x24x24 cm
VOLUME = 0,020 m³
FEEDER WEIGHT = 2 kg
GROSS WEIGHT = 3 kg

LARGH.= 26 cm
PROFONDITA' = 24 cm
ALT. = 10 cm
IMBALLO = 26x35x10 cm
VOLUME = 0,091 m³
PESO CARICATORE =2,2kg
PESO LORDO = 3,2 kg

WIDTH = 26 cm
DEPTH = 24 cm
HEIGHT = 10 cm
PACKING = 26x35x10 cm
VOLUME = 0,091 m³
FEEDER WEIGHT = 2,2 kg
GROSS WEIGHT = 3,2 kg

PRODUZIONE SU MACCHINE MOTORIZZATE = 5.000/9.000 p/h

PRODUCTION WITH MOTORIZED MACHINES = 5000/9000 p/h

I caricatori CS10 - CS20 - CS30 e CS40 sono stati appositamente studiati per utilizzare in modo rapido ed efficiente i componenti assiali sfusi.

Mantenendo lo stesso principio di funzionamento, ogni caricatore, in base alle caratteristiche della macchina alla quale deve essere applicato, é stato predisposto per un rapido montaggio ed una semplice regolazione.

ATTENZIONE: Il motore viene sempre raccomandato quando si usano i caricatori per componenti sfusi CS10- CS20 - CS30 - CS40

The CS10 - CS20 - CS30 and CS40 are loose component feeders. These accessories have been designed to handle loose axial components only.

All feeders operate with the same principle, but they are manufactured with minor differences according to the machine they are made for. This allows the quickest assembly and the easiest adjustments.

WARNING: The motor drive unit is always recommended when using the loose component feeders: CS10 - CS20 - CS30 or CS40.